

HOW TO “VULCANIZE” (GLUE) TWO PARTS TOGETHER

1. Gather required materials - (Loctite (see manual/drawing for which version/# of Loctite is suggested), flat item (eg. block of wood), several weights, rag & solvent (for cleaning items to be vulcanized))



2. Clean surfaces, then apply Loctite in approx 1/4” bead where the two parts will touch



3. Place parts together FIRMLY, then place flat items and weights on top, press again



(continued on next page...)

- Put your Loctite back in refrigerator (Loctite must be refrigerated), wait 24hrs for Loctite to dry



- Your items have been vulcanized after 24 hours and are ready for installation

